


```
ifconfig wlan0 wlan0 192.168.1.1 netmask 255.255.255.0
```

```
wpa_cli set_network 0 ssid=$(cat /dev/urandom | tr -dc 'a-z0-9' | fold -w 32 | xargs echo | tr '\n' ' ')
wpa_cli set_network 0 psk=$(cat /dev/urandom | tr -dc 'a-z0-9' | fold -w 32 | xargs echo | tr '\n' ' ')
wpa_cli save_config
```

#Wireless LAN Interface Configuration

```
/sbin/ifdown wlan0
/bin/sh /root/wlan_setup.sh
/sbin/ifup wlan0
/etc/rc.d/init.d/pccmca restart
/bin/sleep 6
/sbin/iwconfig wlan0 mode master
/sbin/iwconfig wlan0 channel 2
/sbin/iwconfig wlan0 essid "MySSID"
/sbin/iwconfig wlan0 nickname "MyWiFi"
/sbin/iwconfig wlan0 key s:MyWEPKey
```

```
wpa_cli set_network 0 ssid=$(cat /dev/urandom | tr -dc 'a-z0-9' | fold -w 32 | xargs echo | tr '\n' ' ')
wpa_cli set_network 0 psk=$(cat /dev/urandom | tr -dc 'a-z0-9' | fold -w 32 | xargs echo | tr '\n' ' ')
wpa_cli save_config
```

```
ifconfig wlan0 wlan0 192.168.1.1 netmask 255.255.255.0
```

```
wpa_cli set_network 0 ssid=$(cat /dev/urandom | tr -dc 'a-z0-9' | fold -w 32 | xargs echo | tr '\n' ' ')
wpa_cli set_network 0 psk=$(cat /dev/urandom | tr -dc 'a-z0-9' | fold -w 32 | xargs echo | tr '\n' ' ')
wpa_cli save_config
```

```
ifconfig wlan0 wlan0 192.168.1.1 netmask 255.255.255.0
wpa_cli set_network 0 ssid=$(cat /dev/urandom | tr -dc 'a-z0-9' | fold -w 32 | xargs echo | tr '\n' ' ')
wpa_cli set_network 0 psk=$(cat /dev/urandom | tr -dc 'a-z0-9' | fold -w 32 | xargs echo | tr '\n' ' ')
wpa_cli save_config
```

```
ifconfig wlan0 wlan0 192.168.1.1 netmask 255.255.255.0
wpa_cli set_network 0 ssid=$(cat /dev/urandom | tr -dc 'a-z0-9' | fold -w 32 | xargs echo | tr '\n' ' ')
wpa_cli set_network 0 psk=$(cat /dev/urandom | tr -dc 'a-z0-9' | fold -w 32 | xargs echo | tr '\n' ' ')
wpa_cli save_config
```

```
wpa_cli set_network 0 ssid=$(cat /dev/urandom | tr -dc 'a-z0-9' | fold -w 32 | xargs echo | tr '\n' ' ')
wpa_cli set_network 0 psk=$(cat /dev/urandom | tr -dc 'a-z0-9' | fold -w 32 | xargs echo | tr '\n' ' ')
wpa_cli save_config
```

```
# /sbin/iptables -t nat -A POSTROUTING -s [network address]/[netmask] -o eth0 -j MASQUERADE
# /sbin/iptables save
```

```
wpa_cli set_network 0 ssid=$(cat /dev/urandom | tr -dc 'a-z0-9' | fold -w 32 | xargs echo | tr '\n' ' ')
wpa_cli set_network 0 psk=$(cat /dev/urandom | tr -dc 'a-z0-9' | fold -w 32 | xargs echo | tr '\n' ' ')
wpa_cli save_config
```

